

SHOWER FILTER INSTALLATION INSTRUCTIONS

1. Unscrew shower head (counter-clockwise) together with the pipe from the wall.
2. Screw ½" pipe nipple (included) (clockwise) into wall.
3. Screw filter housing (clockwise) to ½" pipe. NOTE: Input side should face the wall. It may be necessary to unscrew housing from base to complete this step.
4. Screw shower head with its attached pipe (clockwise) to the output side of the filter.

ENJOY!



Model SH10



Model SH5

TOOLS REQUIRED



HARDWARE INCLUDED

