

SHOWER CARTRIDGE REPLACEMENT INSTRUCTIONS

1. Slide wrench over housing from bottom up.
2. Proceed to open the housing by turning the wrench counter-clockwise.
3. Remove cartridge from housing.
4. Rinse the housing with water and anti-bacterial soap.
5. Lubricate rubber gasket in the housing with a touch of Vaseline.
Important: Make sure that the gasket is properly in place.
6. Insert new cartridge into housing.
7. Screw housing back on.

ENJOY!

TOOLS REQUIRED

